

## **DIY POOL FENCING - INSTALLATION INSTRUCTIONS**

Installing your new fence is an easy and rewarding way to save big money. Follow these easy steps and you are well on your way.

### **STEP 1: Tools You Will Need**

Tape Measure  
Scissor Shovel/Small Spade  
Level  
String Line  
Drill (reverse) Phillip Head Bit Hex 5/16" Bit  
Crow Bar

### **STEP 2: Lets Start At The Gate**

Dig Holes either side of gate 985mm centre to centre.

Install Hinge post first, 1350mm from ground to top of post. Place rapid set concrete into hole just enough to hold post up on its own, tap it down to make it firm (no water in holes yet.) Repeat for latch post.

Ensure posts have a measurement of 935mm between them and no less than 1500 from ground to the top of the post.

Screw hinges to hinge post facing out, ensure hinges are as far apart on gate as possible.

Install Magna Latch following the instructions on the packaging.

**(Note: Gates should always open away from pool).**

### **STEP 3: Gates On Now – Lets Start First Panel**

String a line to where you want the fence to go using garden stakes or similar to hold the string at each end.

Mark our where your holes will be and dig them only a few at a time. Hole size approx. 200mm dia x 500mm dia.

Using the rail flanges supplied, determine height of the panel on the gate post and attach flange top and bottom of post, feed panel into flanges using a block of wood or brick approx. 80mm high. Place under the panel opposite the flanges you have just fed the panel into.

Pack panel up or down until it is level. Screw tek screw through the Face of flange into the punch top and bottom.

**(Note: Tek screws will strip, take it easy).**

**STEP 4: First Panels On – Now Continue**

Place flanges on next post.

Level panel with block underneath as you did with previous panel.  
Screw panel to flanges.

Check that posts are vertically level to string line and panels are horizontally level. Rapid set post as you did previous.

**STEP 5: Fence All Up**

When you have all the fence panels standing check that everything is level. Now finish the concrete as per instructions on the bag.